

Sliding Door, Metal Panel Mount Overhead to Traxx[®]

Tools Required

- Phillips Screwdriver or Cordless Drill with #2 Phillips Bit
- 7/16" Wrench, Socket, or Nut Driver
- Level

Hardware Required

- Overhead Mounting Brackets (2 each)
- 1/4" Flat Washer (8 each)
- 1/4" Acorn Nut (8 each)
- Ganging Bracket (If installing 2 cabinets side-by-side)
- #8 X 5/8" Phillips Head Sheet Metal Screws (6 each, used with Ganging Brackets)

Installation

1. Remove the inner back panels from the cabinet. Lift the panel straight up using the hole provided near the bottom. Grasp the panel at the top and pull toward you. While holding the panel horizontally with the top facing the front of the cabinet, turn the panel approximately 30 degrees and pull straight out to remove it. (Figure A)
2. Insert the threaded studs on the mounting brackets through the holes on the back of the cabinet. The top inside stud goes through the round hole. The other studs go through the slotted holes.
3. From the inside of the cabinet place a 1/4" flat washer and 1/4" acorn nut on each of the studs. Using a 7/16" wrench, socket, or nut driver, tighten the acorn nuts, making sure that the mounting bracket is square to the cabinet. (Figure B)
4. Repeat for the opposite side.

Figure A





Figure B



Sliding Door, Metal Panel Mount Overhead to Traxx[®]

Installation (continued)

- Using 2 persons, tilt the bottom of the cabinet out approximately 15 degrees and insert the upper tab of the mounting brackets into the groove on the Traxx extrusion. Push the upper tab as far up into the extrusion as possible, then rotate the cabinet back parallel to the wall, allowing the lower hooks of the mounting brackets to swing into the extrusion slot. Lower the cabinet until the lower hooks are fully seated on the lower flange of the extrusion. (Figure C)
- The overhead cabinet may be installed on wall Traxx either with or without a tile installed behind the cabinet. Let the cabinet rest against the wall or against the tile. Place a level on top of the cabinet from front to back. Level the cabinet by loosening the screws on the leveling bracket at the bottom of the cabinet. Slide the leveling bracket forward or backward until the cabinet is level. Re-tighten the screws. (Figure D)
- Re-install the inner panels.
- If cabinets are installed side-by-side, a ganging bracket is required. Attach the ganging bracket to the bottom edges of the end panels of two adjacent cabinets and secure with the #8 X 5/8" sheet metal screws provided. Make sure that the top, bottom and front edges of the cabinet are aligned. It may be necessary to hold the cabinets together with "C" clamps until the ganging bracket can be secured. If "C" clamps are used, use a piece of wood or other non-marring material between the clamps and cabinet and do not over-tighten. (Figure F)

Figure F




Figure C





Figure D

Leveling Bracket
ScrewsCabinet installed on
wall with no tileCabinet installed on
wall with tile