

Support Panel for Desks and Credenzas

Tools Required

- Cordless Drill
- #2 Phillips Head Bit

Hardware Contents

- #8x 5/8" Panhead Screws
- L Brackets

Installation

1. The single pedestal end support is used to support a work-surface when a return or bridge worksurface will gang perpendicular to the primary worksurface. (Figure A)
2. All panels will have pilot holes to be used to locate the L brackets. Attach the L brackets to the panels using the #8X 5/8" screws provided. (Figure B)
3. Attach the L brackets to the top edge of back and end panels using #8X5/8" panhead screws provided.
4. Attach the support panel to the back panel using the #8X5/8" screws provided making sure top surface are flush as shown. (Figure C)
5. Assemble the back panel with the support panel to the end panel using #8X5/8 screws provided making sure the top surfaces are flush as shown. (Figure D)

Figure A




Figure B




Figure C




Figure D

