

KOHLER[®]

TELLIEUR[™] TABLE

INSTALLATION INSTRUCTIONS

MATERIALS NEEDED:

- Adjustable Wrench
- Level
- Square
- Drill
- Measuring Tape
- Pencil
- Safety Glasses
- Fasteners (see **step 9.**)
- Screwdriver

BEFORE YOU BEGIN

1.

Unpack the table, legs, tabletop and any accessories and inspect for damage.

If installing the optional towel bar continue on to **step 2.** otherwise skip to **step 3.**

TOWEL BAR INSTALLATION

2.



WARNING: RISK OF PERSONAL INJURY.

This towel bar is not designed or intended for use as a grab or support bar.

NOTE: Towel bar must be installed prior to the installation of the table legs.


NOTE: Hole placement may appear different for certain table models. Make sure to make measurements from sides as shown in order to ensure proper placement.

Choose which side of the table to install the towel bar.

Measure and mark $\frac{3}{4}$ " from the edge of the chosen side of the table and 2" down from the top edge of the side rail.


Measure distance "A" from the first mark to find location for the second hole. Distance "A" is $11\frac{3}{4}$ " for 19" table widths or $14\frac{3}{4}$ " for 22" table widths.

Drill a hole at each mark using a $\frac{3}{8}$ " bit. Be careful not to drill through the corner brackets of the table.



3.

Insert the towel bar into the holes and secure with washers and nuts. Wrench tighten.



SHELF SUPPORT INSTALLATION

4.

If not installing the optional shelf proceed to **step 7**.


Remove the thread protectors from the leg hanger bolts and discard.

NOTE: You may want to temporarily install the legs and with a pencil lightly "X" the surfaces you will be drilling.

Mark measurements on the front of the back legs and the back of the front legs.


Measure up 8" from the bottom edge of the aluminum foot and 1-1/8" from the edge of the legs.

Drill a 3/8" hole at each mark approximately 1-1/4" into the legs. **Do not drill all the way through.**



5.

Install the back table legs by inserting the leg hanger bolts into the corner brackets and securing in place with the lockwashers and hex nuts.



6.

Insert the brass rods for the shelf fully into the back leg shelf holes.

Insert the brass rod from the back leg into the hole in one of the front legs.


Insert the leg hanger bolt of the front leg into the corner bracket and loosely secure with the lock washer and hex nut.

Repeat for other leg.

Square the legs and table.

Wrench tighten nuts.

Do not install the shelf at this time. Continue on to **step 8**.



LEG INSTALLATION

7.

Remove the thread protectors from the leg hanger bolts and discard.

Take one of the legs and insert the leg hanger bolt into the corner bracket and secure in place with the lock washer and hex nut.

Repeat for other three legs.

Square the legs and table.

Wrench tighten nuts.





TABLE INSTALLATION

8.

Verify that the table is level, both front-to-back and side-to-side. If the table is not level, adjust by turning the leveling feet as needed.

Make sure that the table is supported by all four feet and does not rock.



9.

Find the studs along the wall where the table is to be installed.


Position the table against the wall.

Insert the spacer block(s) between the back table rail and the stud. Position the spacer block so that it rests evenly or just slightly below the top edge of the table rail. Make sure that it does not sit higher than the top edge of the table rail because it may cause the tabletop to not rest flat.

NOTE: The spacer block does have predrilled holes that may be used to secure the block to the stud before drilling through the table. If securing the block to the wall prior to drilling make sure to drill between the two fasteners when securing the table to the wall.

Carefully drill a hole through the back rail of the table, spacer block, finished wall and into the wall stud. Make sure to use a drill of adequate diameter to accommodate fastener (not provided) chosen to secure the table to the wall.

Secure the table to the wall using a screw or bolt of sufficient length to reach into the stud.



TABLETOP PLACEMENT

10.



CAUTION: RISK OF PERSONAL INJURY OR PRODUCT DAMAGE.


Get help lifting the tabletop into place.

Position the tabletop on the table frame. Make sure that the precut hole for the lavatory is in the appropriate place.

Center the tabletop from side-to-side on the frame.

Push tabletop up evenly against the finished wall.

If installing a stainless steel tabletop continue on to **step 11**.
If installing a stone tabletop continue to **step 12**.



STAINLESS STEEL TABLETOP INSTALLATION

11.


Insert one S-bracket into the groove of each of the table rails. Make sure the S-brackets are positioned so not to interfere with the installation of the lavatory.

Mark the locations of each of the S-brackets.

Drill a 1/16" hole approximately 1/2" deep at each mark.

Insert the screws (provided) through the S-bracket and into the holes in the bottom of the tabletop. Tighten securely but do not overtighten.

Continue to **step 13**.




STONE TABLETOP INSTALLATION

12.

Install the S-brackets in the grooves in the table rail.

Align the S-brackets with the pre-installed anchors in the underside of the tabletop.

Insert the machine screws (provided) through the S-bracket and into the holes in the bottom of the tabletop. Tighten securely but do not overtighten.



LAVATORY INSTALLATION


13.

Install the lavatory at this time according to the manufacturer's instructions.

SHELF INSTALLATION

14.

If installing the optional shelf, place the shelf on the brass rods.



CALL US FOR HELP

Questions? Problems? First review the installation instructions to ensure correct installation. For additional assistance in the USA, call our Customer Service Department for direct help. You may also contact us at our web site.

THE BOLD LOOK
OF **KOHLER**®

1-800-4-KOHLER
www.kohlerco.com